

**READ ALL INSTRUCTIONS COMPLETELY AND THOROUGHLY UNDERSTAND THEM BEFORE DOING ANYTHING.
CALL TOTAL CONTROL PRODUCTS TECH SUPPORT (916) 388-0288 IF YOU NEED ASSISTANCE.**

INSTALLATION GUIDE



TCP PCM-01

Pedal Covers, Manual Transmission - 1964-70 Mustang



Description: Billet Pedal Pads, Manual 3 piece set

Applications: Fits Cougar '67-70, Mustang '64-70

WARRANTY NOTICE:

There are NO WARRANTIES, either expressed or implied. Neither the seller nor manufacturer will be liable for any loss, damage or injury, direct or indirect, arising from the use or inability to determine the appropriate use of any products. Before any attempt at installation, all drawings and/or instruction sheets should be completely reviewed to determine the suitability of the product for its intended use. In this connection, the user assumes all responsibility and risk. We reserve the right to change specification without notice. Further, Chris Alston's Chassisworks, Inc., makes **NO GUARANTEE** in reference to any specific class legality of any component. **ALL PRODUCTS ARE INTENDED FOR RACING AND OFF-ROAD USE AND MAY NOT BE LEGALLY USED ON THE HIGHWAY.** The products offered for sale are true race-car components and, in all cases, require some fabrication skill. **NO PRODUCT OR SERVICE IS DESIGNED OR INTENDED TO PREVENT INJURY OR DEATH.**

Total Control Products
A Chris Alston's Chassisworks, Inc. Brand
8661 Younger Creek Drive
Sacramento, CA 95828
Phone: 916-388-0288
Technical Support: tcptech@cachassisworks.com



PARTS LIST

TCP PCM-01 Pedal Covers Manual 64-70 Mustang

Qty	Part Number	Description
1	7915-001	Gas Pedal Cover, Billet Aluminum
1	7915-003	Brake Pedal Cover, Billet Aluminum
1	7915-004	Clutch Pedal Cover, Billet Aluminum
1	7918-037	Hardware Bag

7918-037 - Hardware Bag

Qty	Part Number	Description
12	3101-016-32S	Locknut 8-32 Stainless Steel
12	3105-016C0.75S	Flat Head Cap Screw 8-32 x 3/4" Stainless Steel

INSTRUCTIONS

The photos shown in these instructions were taken on a car with an automatic transmission. The same procedure is used to install the manual transmission pedal cover.

1. Remove rubber covers from OEM pedals.

NOTE: If the gas pedal rubber pad is difficult to remove, the billet pedal cover can be installed on top of the rubber pad.



2. Position billet brake pedal pad over the factory pedal and secure into place using a C-clamp or vise-grip pliers. Use masking tape to protect the pedal cover from being scratched.



- Using the pedal pad as a jig, drill the first hole with a 3/16" (.187") drill bit.



- Bolt the pad to the pedal using a 8-32 x 3/4" flat head cap screw and locknut.



- The remaining holes can now be drilled in succession with the pad being held securely in place by the C-clamp and first bolt.
- When finished drilling, secure the billet pedal covers to pedals using the supplied hardware.
- Tighten hardware, so the pads are seated securely without rocking or movement.
- Over tightening can potentially damage the pads.



9. Clamp the gas pedal pad in place and use the same procedure as the brake pedal to install.



10. Do not over tighten the hardware.



11. Manual transmission vehicles must also install the clutch pedal cover.

12. The installation is complete.

