

**READ ALL INSTRUCTIONS COMPLETELY AND THOROUGHLY UNDERSTAND THEM BEFORE DOING ANYTHING.  
CALL TOTAL CONTROL PRODUCTS TECH SUPPORT (916) 388-0288 IF YOU NEED ASSISTANCE.**

# INSTALLATION GUIDE



## TCP PCA-01

### Pedal Covers, Automatic Transmission - 1964-70 Mustang



**Description:** Billet Pedal Pads, Automatic 2 piece set

**Applications:** Fits Cougar '67-70, Mustang '64-70

#### **WARRANTY NOTICE:**

There are NO WARRANTIES, either expressed or implied. Neither the seller nor manufacturer will be liable for any loss, damage or injury, direct or indirect, arising from the use or inability to determine the appropriate use of any products. Before any attempt at installation, all drawings and/or instruction sheets should be completely reviewed to determine the suitability of the product for its intended use. In this connection, the user assumes all responsibility and risk. We reserve the right to change specification without notice. Further, Chris Alston's Chassisworks, Inc., makes **NO GUARANTEE** in reference to any specific class legality of any component. **ALL PRODUCTS ARE INTENDED FOR RACING AND OFF-ROAD USE AND MAY NOT BE LEGALLY USED ON THE HIGHWAY.** The products offered for sale are true race-car components and, in all cases, require some fabrication skill. **NO PRODUCT OR SERVICE IS DESIGNED OR INTENDED TO PREVENT INJURY OR DEATH.**

Total Control Products  
A Chris Alston's Chassisworks, Inc. Brand  
8661 Younger Creek Drive  
Sacramento, CA 95828  
Phone: 916-388-0288  
Technical Support: [tcptech@cachassisworks.com](mailto:tcptech@cachassisworks.com)



# PARTS LIST

## TCP PCA-01 Pedal Covers Automatic 64-70 Mustang

Qty	Part Number	Description
1	7915-001	Gas Pedal Cover, Billet Aluminum
1	7915-002	Brake Pedal Cover, Billet Aluminum
1	7918-036	Hardware Bag

## 7918-036 - Hardware Bag

Qty	Part Number	Description
8	3101-016-32S	Locknut 8-32 Stainless Steel
8	3105-016C0.75S	Flat Head Cap Screw 8-32 x 3/4" Stainless Steel

# INSTRUCTIONS

1. Remove rubber covers from OEM pedals.

NOTE: If the gas pedal rubber pad is difficult to remove, the billet pedal cover can be installed on top of the rubber pad.



2. Position billet brake pedal pad over the factory pedal and secure into place using a C-clamp or vise-grip pliers. Use masking tape to protect the pedal cover from being scratched.



- Using the pedal pad as a jig, drill the first hole with a 3/16" (.187") drill bit.



- Bolt the pad to the pedal using a 8-32 x 3/4" flat head cap screw and locknut.



- The remaining holes can now be drilled in succession with the pad being held securely in place by the C-clamp and first bolt.
- When finished drilling, secure the billet pedal covers to pedals using the supplied hardware.
- Tighten hardware, so the pads are seated securely without rocking or movement.
- Over tightening can potentially damage the pads.



9. Clamp the gas pedal pad in place and use the same procedure as the brake pedal to install.



10. Do not over tighten the hardware.



11. The installation is complete.

